



Sensores DS Agro



JOHN DEERE



MASSEY FERGUSON



MAP PRESSÃO COLETOR
NEW HOLLAND T7030
T7040 T7050 T7060
T7070 T7220 T7240 T7245
T7260 12> W170B W190B
07> VALTRA BS3120H 14>
DS-117025



VELOCIDADE JOHN DEERE
3520 3522 CH330 CH530
CH570 CH670 CH950
DS-118001



VELOCIDADE JOHN DEERE
7600 7700 7800 7710
7810 PLATAFORMA 600
616 618 620 622 630 635
572 COLHEITADEIRA 565
575 572 582 592 MF5650
(INDUTIVO)
DS-118002



VELOCIDADE JOHN DEERE
9470STS 9670STS
9770STS C670 S540 S550
S650 S660 S670 S680
S690 8100 8200 8300
8400 8500 8600 8700
8800 9500 9700 9800
DS-118005



POSIÇÃO ALTURA
IMPLEMTO JOHN DEERE
864 2200 2210 2230FH
2230LL 2330 2400 2410
2410C 2430 2620 2623
2623VT 2625 2630 2633
2633VT 2635 2720
DS-119001



POSIÇÃO ALTURA JOHN
DEERE 1705 1715 1720 1725
1735 1755 1765 1775 1790
1795 1810 1830 1835 1840
1870 1890 1895 1910 2113
2115 2117 2122 2126
DS-119002



POSIÇÃO PLATAFORMA
CASE 1010 1020 2020 2142
2152 2162 2200 2208 3162
4430 7120 7240 7250 NEW
HOLLAND TC5070
TC5090 880CF 94C
MF5650 MF32
DS-119003



POSIÇÃO PLATAFORMA
JOHN DEERE 600F 600R
614R 615P 615R 616 616F
616R 618 618R 620 620F
620R 622 622F 622R 625
625R 630 630R 635FD
635R
DS-119004



POSIÇÃO PLATAFORMA
CASE 302020FTSD
302025FTSD 302035FTDD
11> NEW HOLLAND 7217
20> TC490 TC590 7220
7225 7230 740CF20
740CF30 19>
DS-119011



POSIÇÃO HIDRÁULICO
JOHN DEERE 7185J 7195J
7200J 7205J 7210J 7215J
7225J 7230J
DS-119013



POSIÇÃO PLATAFORMA
ÂNGULO 12°
COLHEITADEIRA MF6690
MF9250 MF9695 DRAPER
DYNAFLEX FENDT IDEAL 9T
DS-119030



POSIÇÃO PLATAFORMA
ÂNGULO 120° NEW
HOLLAND CR5.85 17>
TC4.90 TC5.90 TX4.90
TX5.90 19> FR450E3
FR450E4 FR500E3
FR500E4 FR600E3
FR700E3 12>15
DS-119035



POSIÇÃO PLATAFORMA
ÂNGULO 100° JOHN
DEERE 3520 7660 7760
9560 9570 9660 9670
9860 9870 7280 7300
7380 7400 7480 7580
7780 7980 5560 5690
DS-119040



ÂNGULO DIREÇÃO JOHN
DEERE 2204 2854 2904
3204 5090M 5090R
5100M 5115M 5125M 400R
408R 410R 412R 600R
612R 616R 6165J 6170J
6170M 6180J 6190J
DS-119041